

10X10FT-BOOTH-08






(2) Printed Graphic Fabric Banner (Optional)




#### **STEP 01**


Connect to make long poles according to labelings.






**STEP 02** Connect long poles with corner poles according to labelings.








**STEP 03** Slide fabric banner on frame from top and zip up at bottom.







#### (1) Hardware




(2) Printed Graphic Fabric Banner (Optional)




**STEP 01** Connect to make long poles according to labelings.







**STEP 02** Connect long poles with corner poles according to labelings.




# STEP 03

Connect support poles onto frame.







STEP 04 Lay down display stand, slide fabric banner on frame from bottom and zip up at top.




# **Booth Set Assembly**












STEP 02 Insert display stands onto feet by pressing their knobs.




STEP 03 Interconnect display stands with C-shaped clips.





#### STEP 04

Insert pole into base, screw clamp with hex wrench, place MDF board onto pole & insert into clamp with screw.






### STEP 05

Screw TV mount with hex wrench.








TV (Excluded, Demo Only)











10X10FT-BOOTH-08

(1) Durable Plastic Hard Case, Aluminum Support Poles



(2) Printed Graphic Fabric Banner



#### STEP 01

Put hard case's top into fabric banner.



### STEP 02

Insert support poles into hard case's top & bottom.



#### **STEP 04**

Wrap fabric banner from bottom to top & twist it to be smooth, lay hard case's intermediate panel on podium's top.

