



INSTRUCTION



10X20FT-BOOTH-29

STEPS

(1) Hardware



x3



x4

(2) Printed Graphic Fabric Banner (Optional)



STEP 01



Connect to make long poles according to labelings.



x3






x4



STEP 02


Connect long poles with corner poles according to labelings.



STEPS


STEP 03

Slide fabric banner on frame from top and zip up at bottom.




STEP 04

Insert display stands onto feet by pressing their knobs.



(1) Hardware




(2) Printed Graphic Fabric Banner (Optional)





STEP 01

Connect to make long poles according to labelings.




STEPS


STEP 02 Connect long poles with corner poles according to labelings.



STEP 03 Connect intermediate tubes.




STEP 04 Slide fabric banner on frame from top and zip up at bottom.



STEPS


Booth Set Assembly



(3) LED Light & Clip



(1) TV Mount & Screw




(2) Arm Clip



STEP 01


Connect display stands with arm clips.



STEPS


STEP 02


Screw TV mount with hex wrench.



STEP 03

Screw light clips at top of display stands, slide lights onto them and adjust their direction.



STEPS**10X20FT-BOOTH-29**

STEPS

(1) Durable Plastic Hard Case, Aluminum Support Poles




(2) Printed Graphic Fabric Banner





STEP 01

Put hard case's top into fabric banner.



STEP 02

Insert support poles into hard case's top & bottom.



STEPS

STEP 04

Wrap fabric banner from bottom to top & twist it to be smooth, lay hard case's intermediate panel on podium's top.

