(1) Hardware



(2) Countertop Panel



(3) Fixing Accessory




(4) Printed Graphic Fabric Banner



STEP 01

Connect to make long poles according to labelings.





Insert poles into fixing accessory until you hear a 'Ding' sound to make poles' knobs clip into it & its concave parts pop out.



STEP 03 Press poles' knobs to clip into countertop's slot.



STEP 04

Wrap fabric banner from top to bottom, put poles into pockets & zip up.

